



Operating and installation instructions


Combined flow regulating valve ASTRA® Plus



DN 15 - 150



DN 200



DN 250 - 400

Contents

1.0 General information on operating instructions	2-2	5.2 Mounting the hand wheel and display in lagged pipe runs	2-7
2.0 Notes on possible dangers	2-2	5.2.1 Removing the hand wheel DN 15 - 150	2-7
2.1 Significance of symbols	2-2	5.2.2 Fitting the hand wheel and display DN 15 - 150	2-7
2.2 Explanatory notes on safety information	2-2	6.0 Putting the valve into operation	2-8
3.0 Storage and transport	2-2	7.0 Care and maintenance	2-8
4.0 Description	2-3	7.1 Application of lubricating nipple / locking screw	2-10
4.1 Scope of applications	2-3	8.0 Troubleshooting	2-10
4.2 Operating principles	2-3	9.0 Troubleshooting table	2-11
4.3 Diagram	2-4	10.0 Dismantling the valve or the top part	2-12
4.3.1 Parts DN 15 - 200	2-4	11.0 Warranty / Guarantee	2-12
4.3.2 Parts DN 250	2-5		
4.4 Technical data - remarks	2-6		
4.5 Marking	2-6		
5.0 Installation	2-6		
5.1 General notes on installation	2-6		

1.0 General information on operating instructions

These operating instructions provide information on mounting and maintaining the fittings. Please contact the supplier or the manufacturer in case of problems which cannot be solved by reference to the operating instructions.

They are binding on the transport, storage, installation, start-up, operation, maintenance and repair.

The notes and warnings must be observed and adhered to.

- Handling and all work must be carried out by expert personnel or all activities must be supervised and checked.

It is the owner's responsibility to define areas of responsibility and competence and to monitor the personnel.


- In addition, current regional safety requirements must be applied and observed when taking the fittings out of service as well as when maintaining and repairing them.

The manufacturer reserves the right to introduce technical modifications at any time.

These Operating Instructions comply with the requirements of EU Directives.

2.0 Notes on possible dangers

2.1 Significance of symbols



Warning of general danger.


2.2 Explanatory notes on safety information

In these Operating and Installation Instructions dangers, risks and items of safety information are highlighted to attract special attention.

Information marked with the above symbol and "**ATTENTION!**" describe practices, a failure to comply with which can result in serious injury or danger of death for users or third parties or in material damage to the system or the environment. It is vital to comply with these practices and to monitor compliance.

All other information not specifically emphasised such as transport, installation, operating and maintenance instructions as well as technical data (in the operating instructions, product documentation and on the device itself) must also be complied with to the fullest extent in order to avoid faults which in turn can cause serious injury to persons or damage to property.

3.0 Storage and transport

	<p>ATTENTION !</p> <ul style="list-style-type: none">- <i>Protect against external force (like impact, vibration, etc.).</i>- <i>Valve mountings such as actuators, handwheels, hoods must not be used to take external forces, e.g. they are not designed for use as climbing aids, or as connecting points for lifting gear.</i>- <i>Suitable materials handling and lifting equipment should be used.</i> <p><i>See catalog sheet for weights.</i></p>
---	--

- At -20°C to +65°C.

- The paint is a base coat to protect against corrosion during transportation and storage. Do not damage paint protection.

4.0 Description

4.1 Scope of applications

Line regulating valves are used for „shut-off and/or throttling of media“.
Valves with a defined characteristic for heating and cooling systems.



ATTENTION !

- Refer to the data sheet for applications, limits on use and possibilities.
- Certain media require or preclude the use of special materials.
- The valves are designed for standard operating conditions. If conditions exceed these requirements, e.g. aggressive or abrasive media, the operator should state the higher requirements when ordering.
- Valves made from grey cast iron are not authorised for use in systems subject to TRD 110.

The information complies to the Pressure Equipment Directive 97/23/EC.

It is the responsibility of the machine planner to ensure compliance.

The special markings on the valve must be taken into account.

Refer to the catalogue sheet to see which materials are used in standard versions.

Please contact the supplier or the manufacturer if you have any questions.

4.2 Operating principles

The valve is closed (cone/seating function) by turning the hand wheel clockwise. Do not use tools to increase the torque on the hand wheel. The valve stem is sealed by a bellows and an outer safety stuffing box.

The position of the valve cone is shown on the digital display every complete turn and every tenth and five-hundredths of a turn, is also shown (DN 15 - 150)

Over DN 200 the lift is seen on the lift indicator.




Fig. 1: DN 15- 150 with digital display




Fig. 2: ≥ DN 200 with lift indicator

4.3 Diagram

Refer to the data sheet for information about materials with designations and figure numbers.




Fig. 3: DN 15 - 150 with digital display




Fig. 4: DN 200 with lift indicator

4.3.1 Parts DN 15 - 200

Pos.	Designation
1	Body
1.2	Seat ring
2	Bonnet
3	Plug
4	Stem
5	Handwheel
6	Packing ring
7	Stud
8	Hexagon nut
9	Gasket
10	Spring-type straight pin
11	Packing follower
12	Screw joint
13	Removable lock washer
14	Spring-type straight pin
15	Insert nuts
16	Washer

Pos.	Designation
19	Guard cap
22	Stem ring
23	Sicherungsblech
33	Hexagon nut
32	Flange cover
34	Hexagon nut
36	Round head grooved pin
37	Snap ring
38	Lubricating nipple
40	Sealing ring
41	Pressure gauge stud G1/4"
42	Hexagon guard cap
43	Scale
44	Scale ring
76	Digital display
77	Indicator ring




Fig. 5: DN 250 with stuffing box packing and lift indicator

4.3.2 Parts DN 250

Pos.	Designation
1	Body
2	Bonnet
3	Plug
4	Stem
5	Handwheel
6	Packing ring
7	Stud
8	Hexagon nut
9	Gasket
10	Straight pin
11	Washer
12	Hexagon nut
13	Clamp ledge
14	Hexagon screws
15	Insert nuts
16	Washer
17	Packing box flange

Pos.	Designation
18	Guide bushing
19	Guard cap
21	Flap type screw
22	Washer
23	Hexagon nut
24	Straight pin
25	Scale
26	Scale ring
27	Round head grooved pin
28	Pressure gauge stud G1/4"
29	Sealing ring
30	Lubricating nipple
31	Spring ring
32	Hexagon nut
33	Hexagon screws
34	Hexagon guard cap

4.4 Technical data - remarks

for

- Principal dimensions
- Pressure-temperature-ratings, etc. see datasheet.

4.5 Marking

Details of the CE-marking on the valve:



CE-marking

0525 Notified body



Manufacturer

Address of manufacturer:

refer to item 11.0 Warranty / Guarantee

Typ Type

Bj. Year of manufacture

According to the Pressure Equipment Directive table 6, annex II, valves without safety function are only allowed to bear the CE-marking DN32 onwards.

5.0 Installation

5.1 General notes on installation

The following points should be taken into account besides the general principles governing installation work:



ATTENTION !

- Remove flange covers if present.
- The interior of valve and pipeline must be free from foreign particles.
- Note installation position with reference to flow, see mark on valve.
- Steam line systems should be designed to prevent water accumulation.
- Lay pipelines so that damaging transverse, bending and torsional forces are avoided.
- Protect valves from dirt during construction work.
- Connection flanges must mate exactly.
- Connecting bolts for pipe flanges should be mounted preferably from the counter flange side (hexagon nuts from the valve side).
At DN15-32: If valves should be mounted directly to valves, the upper flange connecting bolts should be preferably executed with studs and hexagon nuts on both sides.
- Valve mountings such as actuators, handwheels, hoods must not be used to take external forces, e.g. they are not designed for use as climbing aids, or as connecting points for lifting gear.
- Suitable materials handling and lifting equipment should be used.
See data sheet for weights.

- Valves can be installed with the spindle pointing in any direction, but the preferred spindle position is vertical.
- Valves should be installed upside down only, if the medium being handled is clean.
- Centre gaskets between the flanges.
- It is forbidden to heat the valve to above its service temperature (see data sheets), for instance by welding, grinding, etc.
- To ensure that the valves function correctly, the pipe run should be straight for at least 6 x DN upstream and 2 x DN downstream of the valve.

- Planners / construction companies or operators are responsible for positioning and installing products.
- The valves are designed for application, not influenced from weather.
- For application outside or in adverse environments like corrosion-promoting conditions (sea water, chemical vapours, etc.), special constructions or protective measures are recommended.

5.2 Mounting the hand wheel and display in lagged pipe runs

5.2.1 Removing the hand wheel DN 15 - 150

1. Close the valve by hand (pos. 5) ("0" position).



ATTENTION !

- The handwheel must be secured (hold tight) when removing the protection cap

2. Unscrew the protection cap (pos. 19).
3. Lift off the hand wheel (pos. 5) and the digital display.

5.2.2 Fitting the hand wheel and display DN 15 - 150

1. Set the digital display (pos. 76) in place.
2. Set the hand wheel (pos. 5) in place.
3. Screw on the protection cap (pos. 19):
 - DN 15- 80 = 30 Nm
 - DN 100-200 = 40 Nm




Fig. 6

6.0 Putting the valve into operation



ATTENTION !

- Before putting the valve into operation, check material, pressure, temperature and direction of flow.
 - Regional safety instructions must be adhered to.
 - Residues in piping and valves (dirt, weld beads, etc.) inevitably lead to leakage.
 - Touching the valve when it is operating at high ($> 50^{\circ}\text{C}$) or low ($< 0^{\circ}\text{C}$) media temperatures can cause injury.
- Affix warning notice or protective insulation as appropriate!

Before putting a new plant into operation or restarting a plant after repairs or modification, always make sure that:

- All works has been completed!
- The valve is in the correct position for its function.
- Safety devices have been attached.

- Proprietary measuring instruments (e.g. ARImetec-DX, ARImetec-D) can be used for hydraulic calibration.
- The operating instructions for the measuring instruments must be observed.

7.0 Care and maintenance

- Maintenance and maintenance-intervals have to be defined by the operator according to the requirements.




Fig. 7: DN15-200




Fig. 8: DN250-400

- Keep the spindle well greased!
- Lubricant: e.g. Klüberpaste HEL 46-450 (at valves for oxygen: Klüberalfa YV93-302)
- to order at: Klüber Lubrication München KG, Postfach 701047, D-81310 München or a lubricant wich is suitable for the application.



ATTENTION !

Pay attention, that the lubricant is suitable for the media.

- If the stem (pos. 4.2) starts leaking, tighten the bolted gland (pos. 12) until leaking stops

DN250-400:

- If the spindle (pos. 4.2) starts leaking, tighten the stuffing box (pos. 17) with the hexagonal nut (pos. 23) until leaking stops.



ATTENTION !

- *Retighten the stuffing box packing if required and re-pack it in good time.*
- *For safety reasons we recommend that valves only be repacked when depressurised.*
- **See point 10.0 and 11.0 before dismantling the valve.**




Fig. 9: Split packing ring

- When cutting the new packing von der Schnur, make sure that the ends are cut with a slant (see Fig. 9)

Mounting of the bonnet:

- Before reassembling the unit, remember that the bearing surface must be cleaned and 2 new gaskets (pos. 9) must be inserted.
- Set the cover in place
- Tighten the hexagon nuts (hexagon screws for valves of cast iron) evenly crosswise.
- Tightening torque's for hexagon nuts / screws:

DN	hexagon nuts / hexagon screws	Torque (Nm)
15- 32	M 10	15-30
40- 65	M 12	35-50
80-100	M 16	75-100
125-150	M 16	80-120
200	M 20	150-200
250-400	M 24	340-410

7.1 Application of lubricating nipple / locking screw

ASTRA®-Plus DN 15 - 200

1. Lubrication

(Lubricating nipple acc. to DIN 3405, lubricate with grease press with extrusion die.)

2. Locking screw

(Locking the handwheel by turning the thread pin with hexagon socket clockwise.)




Fig. 10

ASTRA®-Plus DN 250 - 400

1. Lubrication

(Lubricating nipple not screwed in up to the stop, handwheel is not clamped.)

2. Locking screw

(Locking the handwheel by turning the lubricating nipple clockwise.)

3. Lubrication and locking

(Lubrication is possible with the handwheel locked.)




fig. 11

8.0 Troubleshooting

In the event of malfunction or faulty operating performance check that the installation and adjustment work has been carried out and completed in accordance with these Operating Instructions.



ATTENTION !

It is essential that the safety regulations are observed when identifying faults.

If malfunctions cannot be eliminated with the help of the following table

“9.0 troubleshooting table”, the supplier or manufacturer should be consulted.

9.0 Troubleshooting table



ATTENTION !

- read point 10.0 and 11.0 prior to dismantling and repair work !
- read point 6.0 before restarting the plant !

Fault	Possible cause	Corrective measures
No flow	Valve closed.	Open valve.
	Flange covers not removed.	Remove flange covers.
Little flow	Valve not sufficiently open.	Open valve.
	Dirt sieve clogged.	Clean / replace sieve.
	Piping system clogged.	Check piping system.
Valve difficult to move or cannot be opened	Wrong direction of rotation	Turn in correct direction (anticlockwise to open valve).
	Safety stuffing box tightened too strong.	Loosen safety stuffing box slightly.
Valve stem leaking	Bellows seal damaged.	Replace top of bellows seal at earliest opportunity!
	Gland screw (pos. 12) slack.	Tighten gland screw (pos. 12) until leakage stops. Replace top part at earliest opportunity!
	Stuffing box gland DN250-500 (pos. 17) slack (fig. 4).	Tighten stuffing box gland (pos. 17) until leakage stops. -Hex. nut (fig. 4). Replace top part at earliest opportunity!
		If necessary, renew packing in stuffing box seal (pos. 6). Observe warnings!
Leakage across valve seat.	Valve not properly closed.	Pull hand wheel tight without tools.
	Seat (pos. 1/1.2) / plug (pos. 3) damaged by foreign particles. (Fig. 3/4).	Replace valve, consult supplier/manufacturer.
	Pressure difference too high.	Check system pressure and pressure drop (max. $\Delta p = 16$ bar up to DN125). Reduce system pressure.
	Medium contaminated (suspended solids).	Clean valve. Install dirt screen upstream of valve.
Valve with lift limiter cannot be opened.	Lift limiter on stem stop has been tightened.	Turn lift limiter upwards.
Flange broken between valve and piping.	Bolts tightened unevenly. Mating flanges not properly aligned.	Re-align piping and fit new valve!
Display does not show "0"/"0" when valve is closed.	Display not fitted properly after pipe was lagged.	Close valve, unscrew cap (pos. 19), remove hand wheel and digital display, set display to "0"/"0" and reassemble in reverse order. (See point 5.2).
False data recorded.	False data displayed.	See point 5.2. Observe operating instructions for measuring instrument used.

10.0 Dismantling the valve or the top part



ATTENTION !

The following points must be observed:

- *Pressureless pipe system.*
- *Medium must be cool.*
- *Plant must be drained.*
- *Purge piping systems in case of caustic, inflammable, aggressive or toxic media.*

11.0 Warranty / Guarantee

The extent and period of warranty cover are specified in the "Standard Terms and Conditions of Albert Richter GmbH & Co. KG" valid at the time of delivery or, by way of departure, in the contract of sale itself.

We guarantee freedom of faults in compliance with state-of-the-art technology and the confirmed application.

No warranty claims can be made for any damage caused as the result of incorrect handling or disregard of operating and installation instructions, datasheets and relevant regulations.

This warranty also does not cover any damage which occurs during operation under conditions deviating from those laid down by specifications or other agreements.

Justified complaints will be eliminated by repair carried out by us or by a specialist appointed by us.

No claims will be accepted beyond the scope of this warranty. The right to replacement delivery is excluded.

The warranty shall not cover maintenance work, installation of external parts, design modifications or natural wear.

Any damage incurred during transport should not be reported to us but *rather* to the competent cargo-handling depot, the railway company or carrier company immediately or else claims for replacements from these companies will be invalidated.



Technology for the Future.
GERMAN QUALITY VALVES

ARI-Armaturen Albert Richter GmbH & Co. KG, D-33756 Schloß Holte-Stukenbrock

Telephone (+49 5207) 994-0 Telefax (+49 5207) 994-158 or 159

Internet: <http://www.ari-armaturen.com> E-mail: info.vertrieb@ari-armaturen.com