


Operating and installation instructions

Ball float steam traps


CONA[®]S (PN16 - 40)



PN16

- with flanges

(series 630....1)



PN40

- with flanges

(series 630....1)

- with screwed sockets

(series 630....2)

- with socket weld ends

(series 630....3)

- with butt weld ends

(series 630....4)

Contents

1.0 General information on operating instructions	2	5.5 Installation position	8
2.0 Notes on possible dangers	2	5.5.1 Possible installation positions	8
2.1 Significance of symbols	2	5.5.2 Installation with pressure compensation line	9
2.2 Explanatory notes on safety information	2	6.0 Putting the valve into operation	9
3.0 Storage and transport	2	7.0 Care and maintenance	10
4.0 Description	3	7.1 Cleaning / replacing controller assembly	10
4.1 Scope of application	3	7.2 Changing the installation position	11
4.2 Operating principles	3	7.3 Options blow down valve / manual air vent valve	12
4.3 Diagram	4	7.4 Union for pressure compensation line / external vent	12
4.4 Technical data - remarks	5	7.5 Tightening torques	13
4.5 Marking	5	8.0 Troubleshooting	13
5.0 Installation	6	9.0 Troubleshooting table	14
5.1 General notes on installation	6	10.0 Dismantling the valve or the body	15
5.2 Installation instructions for welding	7	11.0 Warranty / Guarantee	15
5.3 Controller adjustment	7	12.0 EC declaration of conformity	16
5.4 Steam trap testing through ultrasonic measurement	7		

1.0 General information on operating instructions

These operating instructions provide information on mounting and maintaining the fittings. Please contact the supplier or the manufacturer in case of problems which cannot be solved by reference to the operating instructions.

They are binding on the transport, storage, installation, start-up, operation, maintenance and repair.

The notes and warnings must be observed and adhered to.

- Handling and all work must be carried out by expert personnel or all activities must be supervised and checked.

It is the owner's responsibility to define areas of responsibility and competence and to monitor the personnel.

- In addition, current regional safety requirements must be applied and observed when taking the fittings out of service as well as when maintaining and repairing them.

The manufacturer reserves the right to introduce technical modifications at any time.

These Operating Instructions comply with the requirements of EU Directives.

2.0 Notes on possible dangers

2.1 Significance of symbols



Warning of general danger.


2.2 Explanatory notes on safety information

In these operating and installation instructions dangers, risks and items of safety information are highlighted to attract special attention.

Information marked with the above symbol and "**ATTENTION !**" describe practices, a failure to comply with which can result in serious injury or danger of death for users or third parties or in material damage to the system or the environment. It is vital to comply with these practices and to monitor compliance.

All other information not specifically emphasised such as transport, installation, operating and maintenance instructions as well as technical data (in the operating instructions, product documentation and on the device itself) must also be complied with to the fullest extent in order to avoid faults which in turn can cause serious injury to persons or damage to property.

3.0 Storage and transport



- At -20°C to +65°C.

- The paint is a base coat to protect against corrosion during transportation and storage. Do not damage paint protection.

4.0 Description

4.1 Scope of application

Float-type steam traps with level control are used for the drainage of systems with compressed air or aqueous gases.



ATTENTION !

- Refer to the data sheet for applications, limits on use and possibilities.
- Certain media require or preclude the use of special materials.
- The valves are designed for standard operating conditions. If conditions exceed these requirements, e.g. aggressive or abrasive media, the operator should state the higher requirements when ordering.
- Valves made from grey cast iron are not authorised for use in systems subject to TRD 110.

The information complies to the Pressure Equipment Directive 97/23/EC.

It is the responsibility of the machine planner to ensure compliance.

The special markings on the valve must be taken into account.

Refer to the catalogue sheet to see which materials are used in standard versions.

Please contact the supplier or the manufacturer if you have any questions.

4.2 Operating principles

(refer to Fig. 5 page 11)

The steam trap is controlled by a swivel-mounted ball float (Pos. 24.16). If condensate is flowing into the steam trap, the ball float (Pos. 24.16) floats up and opens the discharge valve via a lever mechanism. Once the valve is open, the differential pressure between the steam and condensate systems forces the condensate out through the valve.

If the amount of condensate decreases or if there is no condensate, the ball float (Pos. 24.16) falls and shuts the discharge valve.

The valve ball (Pos. 24.4) also works with the seat (Pos. 24.1) as a non-return valve.

The condensate must be able to flow towards the valve at a constant gradient. If there is a possibility that the trap could be air locked, a pressure compensation line must be led back to the system from the top of the hood to guarantee safe functioning of the controller (see Fig. 4).

4.3 Diagram




Fig. 1: CONA[®]S - series 630 PN16




Fig. 2: CONA[®]S - series 630 PN40

Refer to the data sheet for information about materials with designations and figure numbers.

4.4 Technical data - remarks

for

- Principal dimensions,
- Pressure-temperature-ratings, operating limits,
- Valves with different types of connection , etc.
refer to datasheet.

4.5 Marking

Details of the CE-marking on the valve:

CE CE-marking

0045 Notified body

AWH Manufacturer

Anschrift des Herstellers:
siehe Pkt 11.0 Garantie / Gewährleistung

Typ Type

Bj. Year of manufacture

According to the Pressure Equipment Directive appendix 2 diagram 7 valves acc. to article 1 paragraph 2.1.2 (pipes) only show the CE-marking from DN40 onwards.

5.0 Installation

5.1 General notes on installation

The following points should be taken into account besides the general principles governing installation work:



ATTENTION !

- *Remove flange covers if present.*
- *The interior of valve and pipeline must be free from foreign particles.*
- *It is possible to install the float steam trap for vertical or horizontal flow. Note installation position with reference to flow, see mark on valve.*
- *Steam and air line systems should be designed to prevent water accumulation.*
- *Lay pipelines so that damaging transverse, bending and torsional forces are avoided.*
- *Protect valves from dirt during construction work.*
- *Connection flanges must mate precisely.*
- *Valves must not be used to take external forces, e.g. they are not designed for use as climbing aids, or as connecting points for lifting gear.*
- *Suitable materials handling and lifting equipment should be used.*
See data sheet for weights.
- *Centre gaskets between the flanges.*
- *Precautions against freezing should be taken as a matter of course in any facilities susceptible to frost. If a system not in operation is in a position susceptible to freezing, we recommend that the drain plug (Pos. 50) on the unpressurised steam trap be unscrewed, the residual condensate drained off, the seal faces cleaned and the plug screwed down again.*
The sealing ring (Pos. 49) should be replaced if necessary.
(see Fig. 1 - Fig. 2 page 4)

- *Planners / construction companies or operators are responsible for positioning and installing products.*
- *The valves are designed for application, not influenced from weather.*
- *For application outside or in adverse environments like corrosion-promoting conditions (sea water, chemical vapours, etc.), special constructions or protective measures are recommended.*

5.2 Installation instructions for welding

(refer to Fig. 2 page 4)

Please note that only qualified persons using appropriate equipment and working in accordance with technical rules are allowed to install fittings by welding.

The responsibility for this lies with the system owner.

Please refer to the catalogue sheet for information on type and instructions relating to welding socket weld ends/butt weld ends.

When welding products to the pipeline system they should be adequately cooled to prevent any adverse effect on the complete controller assembly (Pos. 24) or possibly the flat gasket (Pos. 17). The heat-affected zone should be restricted to the immediate weld seam area!

Note pre- and post-welding heat treatment in accordance with Material Fact Sheet DIN EN 10222.

5.3 Controller adjustment

The controller is set by the manufacturer as stated in the order and does not need changing. Should the operating parameters have changed fundamentally compared with the particulars in the order, please contact the manufacturer to change the controller adjustment!

5.4 Steam trap testing through ultrasonic measurement

Testing the operation of the steam trap in the installed state is straightforward with the "ARImetec[®]-S" multifunctional testing device.

Refer to data sheet "ARImetec[®]-S".

5.5 Installation position


(refer to Fig. 3 and Fig. 5 page 11)

The float steam trap can be installed for vertical or horizontal flow. This should be stated when ordering.

If the installation position is not stated it will be supplied for vertical flow.


It is possible to change the installation position at a later stage (see 7.2).

However the steam trap must always be installed so that the ball float (Pos. 24.16) can work in a vertical plane.




ATTENTION !
The union for the pressure compensation line (Pos. 52) at the hood (Pos. 16) must point up!


5.5.1 Possible installation positions



Horizontal installation:
Inlet from the left side (ZL)



Vertical installation (standard):
Inlet from the top



Horizontal installation:
Inlet from the right side (ZR)




Fig. 3

5.5.2 Installation with pressure compensation line



ATTENTION !

The installation of a pressure compensation line for gas return is always recommended; especially if the ball float steam trap is installed horizontally.




Fig. 4

6.0 Putting the valve into operation



ATTENTION !

- Before putting the valve into operation, check material, pressure, temperature and direction of flow.
 - Regional safety instructions must be adhered to.
 - Residues in piping and valves (dirt, weld beads, etc.) inevitably lead to leakage.
 - Touching the valve when it is operating at high ($> 50\text{ °C}$) or low ($< 0\text{ °C}$) media temperatures can cause injury.
- Affix warning notice or protective insulation as appropriate.*

Before putting a new plant into operation or restarting a plant after repairs or modification, always make sure that:

- All works has been completed.
- The valve is in the correct position for its function.
- Safety devices have been attached.

7.0 Care and maintenance

Maintenance and maintenance intervals have to be defined by the operator according to the requirements.



ATTENTION !

- **refer to item 10.0 and 11.0 prior to dismantling and repair work !**
- **refer to item 6.0 before restarting the plant !**

Prior to installation, threads and seal faces should be coated with temperature-stable lubricant (e.g. "OKS Anti-Seize Paste" white/metal-free)

7.1 Cleaning / replacing controller assembly

(refer to Fig. 1- Fig. 2 page 4 and Fig. 5 page 11)

- Dismantle hood (Pos. 16) by slackening hexagonal nuts (Pos. 28).
- Slacken union (Pos. 52) to remove pipeline at pressure compensation line.
- Remove dirt from body (Pos. 1) and hood (Pos. 16); tiny dirt particles can be removed by flushing out the ducts and rinsing the body (Pos. 1). Clean the strainer (Pos. 2).
- If necessary dismantle the float controller (Pos. 24) and clean separately or change float controller.
- Unscrew the hollow-core screw (Pos. 24.10) of the float controller (Pos. 24) from the body (Pos. 1).
- Pull complete float controller (Pos. 24) out to remove, taking care with the sealing ring (Pos. 11).
- Do not make any changes to spindle adjustment (Pos. 24.3), the float controller (Pos. 24) is set by the manufacturer (except in the case of extremely high back pressures, when please consult the manufacturer).
- Check lifting force of ball float (Pos. 24.16) by immersing the whole controller (Pos. 24) in a water bath with the vent tube (Pos. 24.12) pointing upwards the spindle (Pos. 24.3) in a horizontal position. When immersed in the water bath the ball (Pos. 24.16) must float to the top. If the ball float (Pos. 24.16) sinks (i.e. goes under) the complete controller (Pos 24) should be replaced!
- The flat gasket (Pos. 17) and sealing ring (Pos. 11) should be replaced.
- Assemble in reverse order (refer to item 7.5).

7.2 Changing the installation position

(see Fig. 1- Fig. 2 page 4 and Fig. 3 page 8)

- Position body (Pos. 1) as desired, bearing in mind the direction of flow.
- Remove hood (Pos. 16), then slacken hollow-core screw (Pos. 24.10) approximately 1/2 turn.
- Rotate controller (Pos. 24) 90° in the direction required.



ATTENTION !

The union for the pressure compensation line (Pos. 52) at the hood (Pos. 16) must point up!

- Tighten hollow-core screw (Pos. 24.10) by holding against nozzle part (Pos. 24.11).
- Inspect and if necessary replace body seal (Pos. 17).
- Put on hood (Pos. 16) with the drain plug (Pos. 50) pointing diagonally down.
- Fit hexagonal nuts (Pos. 28) (see 7.5) and tighten crosswise.
- Reconnect pressure compensation pipe to the union for the pressure compensation line (Pos. 52).




Fig. 5: Controller, cpl.

7.3 Options blow down valve / manual air vent valve

(refer to Fig. 1 page 4 and Fig. 6)



ATTENTION !

Escape of hot medium under pressure!
Observe item 2.2 !

Accumulated dirt and condensate can be removed from the hood (Pos. 16) through the blow down valve by opening the pressure screw (Pos. 46.1). When opening, hold against blow down valve (Pos. 46).

Accumulating inert gases can also be discharged to the environment with the manual air vent valve (Pos. 51) by opening the pressure screw (Pos 51.1).

During operation it is imperative to observe general working safety conditions and possibly fit devices to guard against scalding/injury.

Note section 7.5 when installing and operating the option.





Fig. 6

7.4 Union for pressure compensation line / external vent

(refer to Fig. 4 page 9)

It is possible to return the accumulating gases to the system by connecting a pressure compensation line to the union (Pos. 52).

Note section 7.5 when installing the option.

Pressure compensation pipe

Ermeto connection: external pipe diameter 8 mm

When delivered the Ermeto connection is sealed by a 12 mm diameter stainless steel ball.

Remove this ball when installing the pressure compensation pipe.




Fig. 7

7.5 Tightening torques

(refer to Fig. 1 page 4 - Fig. 6 page 12)

Pos.	CONA S PN16	Torque (Nm)		
		DN15-20	DN25	DN32-50
24	Controller	60	60	100
24.8	Hex. nut M4 / M4 / M6	5	5	10
50	Plug	50	50	50
27	Cheese head screw M10 / M12 / M16	15	25	50
51	Manual air vent valve	50	50	50
51.1	Pressure screw	30	30	30
46	Blow down valve	50	50	50
46.1	Pressure screw	30	30	30
52	Union for pressure compension line	50	50	50

Pos.	CONA S PN40	Torque (Nm)		
		DN15-20	DN25	DN32-50
24	Controller	60	60	100
24.8	Hex. nut M4 / M6	5	5	10
28	Hex. nut M12 / M12 / M16	25	30	60
50	Plug	70	70	70
51	Manual air vent valve	70	70	70
51.1	Pressure screw	30	30	30
46	Blow down valve	70	70	70
46.1	Pressure screw	30	30	30
52	Union for pressure compension line	70	70	70

8.0 Troubleshooting

In the event of malfunction or faulty operating performance check that the installation and adjustment work has been carried out and completed in accordance with these Operating Instructions.



ATTENTION !

- It is essential that the safety regulations are observed when identifying faults.

If malfunctions cannot be eliminate with the help of the following table
“9.0 Troubleshooting table”, the supplier or manufacturer should be consulted.

9.0 Troubleshooting table



ATTENTION !

- refer to item 10.0 and 11.0 prior to dismantling and repair work !
- refer to item 6.0 before restarting the plant !

Fault	Possible cause	Corrective measures
No flow	Installed in wrong flow direction	Fit valve in direction of flow arrow. Note installation position; refer to item 5.5.1!
	Flange covers not removed	Remove flange covers
	Ball float (Pos. 24.16) defective	Check lifting force; refer to item 7.1
	Condensate cannot get to steam trap due to bad pipeline routing.	Note installation position; refer to item 7.4
Reduced flow	Wrong installation position	Correct installation position; refer to item 5.5.1! Correct installation position; refer to item 7.2
	Strainer clogged (Pos. 2)	Clean strainer; refer to item 7.1
	Piping system clogged	Check piping system
	Wrong controller size chosen	Correct selection acc. to flow diagram
	Changed upstream pressure or back pressure operating conditions	Correct selection acc. to flow diagram
	Ball float (Pos. 24.16) prevented from swivelling, particularly in horizontal installation position	Use pressure compensation line option; refer to item 7.4
No closure, or internal leakage	Controller clogged	Clean strainer and controller; refer to item 7.1
	Controller worn out	Change controller; refer to item 7.1
	Controller incorrectly screwed into body	Check seal face between body and controller, tighten controller correctly; refer to item 7.5
	Controller operated above safe operating pressure	Observe operating limits as per data sheet, i.e. possibly select different controller
External leakage	Hood (Pos. 16) not properly tightened with hex. nut (Pos. 28) or cheese-head screw (Pos. 27)	Tighten; refer to item 7.5
	Flat gasket (Pos. 17) defective.	Replace sealing; see 7.1

10.0 Dismantling the valve or the body



ATTENTION !

The following points must be observed:

- *Pressureless pipe system.*
- *Medium must be cool.*
- *Plant must be drained.*

11.0 Warranty / Guarantee

The extent and period of warranty cover are specified in the "Standard Terms and Conditions of Albert Richter GmbH & Co. KG" valid at the time of delivery or, by way of departure, in the contract of sale itself.

We guarantee freedom of faults in compliance with state-of-the-art technology and the confirmed application.

No warranty claims can be made for any damage caused as the result of incorrect handling or disregard of operating and installation instructions, datasheets and relevant regulations.

This warranty also does not cover any damage which occurs during operation under conditions deviating from those laid down by specifications or other agreements.

Justified complaints will be eliminated by repair carried out by us or by a specialist appointed by us.

No claims will be accepted beyond the scope of this warranty. The right to replacement delivery is excluded.

The warranty shall not cover maintenance work, installation of external parts, design modifications or natural wear.

Any damage incurred during transport should not be reported to us but *rather* to the competent cargo-handling depot, the railway company or carrier company immediately or else claims for replacements from these companies will be invalidated.



Technology for the Future.

GERMAN QUALITY VALVES

ARI-Armaturen Albert Richter GmbH & Co. KG, D-33756 Schloß Holte-Stukenbrock

Telephone (+49 5207) 994-0 Telefax (+49 5207) 994-158 or 159

Internet: <http://www.ari-armaturen.com> E-mail: info.vertrieb@ari-armaturen.com

12.0 EC declaration of conformity



AWH Armaturenwerk Halle GmbH,
Turmstrasse 118, D-06110 Halle/Saale

EC declaration of conformity
as defined by
the Pressure Equipment Directive 97/23/EC

Herewith we declare,

that according to the above mentioned Pressure Equipment Directive (PED) the below listed products comply and have been approved according to Module B1+D through TÜV Hannover/Sachsen Anhalt e.V. (BS-No. 0045), Saalfelder Strasse 33-34, 06116 Halle/Saale.

Ball float steam traps **CONA[®]S**

Series	Nom. press.	Material	DN	Certificate-No.
630	PN 40	0.7043	40-50	07 202 6111 Z 0016/1/E 02
630	PN 40	1.0460; 1.4541	40-100	07 202 6736 Z 0016/2/E 31;...32;...33;...34
630	Class 300	SA105; SA182F321	1 1/2" - 4"	0662/126/02

Applied standards:

DIN 3840
AD 2000-leaflet
ASME VIII/1

Halle/Saale, 06.04.2004



(Dr. Urbanek, Managing director)